



USER MANUAL FOR PRE-PAYMENT METERS

LIBERTY 1P & LIBERTY 3P

KEYPAD INSTRUCTION

- Key * Button before entering recharge code.
- Key # Button after entering recharge code
- Key 1 Credit left in days, your present load & load cost per hour
- Key 2 Previous day's, Previous week's, Previous month's expenditure in Rupees.
- Key 3 Unit rates of electricity.
- Key 4 The last five recharge codes keyed in.
- Key 5 ABC Code / Total money entered into meter.
- Key 6 Voltage, Current, Power Factor & Frequency
- Key 7 Standing Charges (Fixed charge)
- Key 8 Monthly maximum demand with date & time.
- Key 9 Total energy units (kWh).
- Key 0 Display test, time, date, code

INSTRUCTION FOR CONSUMER

1. How to set low balance alarm: For example to set alarm at :

Rs 1000/-	Press	*00000010007#
Rs 100/-	Press	*00000001007#
Rs 150/-	Press	*00000001507#
Rs 50/-	Press	*00000000507#